

CE

Approved for Digital  
Weigh Indicator

# Digital Weighing Indicator SI 300

## Instruction Manual



 **SEWHACNM**  
주식회사 세화씨엔엠

# CONTENTS

<b>1. Before Installation</b>	-----	<b>3 Page</b>
<b>2. Introduction</b>	-----	<b>4 Page</b>
<b>3. Specification</b>	-----	<b>5 Page</b>
3-1. Specification	-----	5 Page
3-2. Front Panel	-----	6 Page
3-3. Rear Panel	-----	8 Page
<b>4. Installation</b>	-----	<b>9 Page</b>
4-1. Dimension & Cutting Size	-----	9 Page
4-2. Installation Components	-----	9 Page
4-3. Load Cell Installation	-----	10 Page
<b>5. Set up</b>	-----	<b>11 Page</b>
5-1. Set Up mode	-----	11 Page
5-2. TEST Weight Calibration Mode	-----	12 Page
5-3. Simulating Calibration Mode	-----	16 Page
5-4. F-FUNCTION Setting	-----	21 Page
5-5. Test Mode	-----	28 Page
<b>6. Interface</b>	-----	<b>30 Page</b>
6-1. Serial Interface	-----	30 Page
6-2. Serial Print	-----	40 Page
<b>7. Error &amp; Treatment</b>	-----	<b>41 Page</b>
7-1. Load Cell Error & Treatment	-----	41 Page
7-2. Calibration Error & Treatment	-----	42 Page
7-3. Indicator Error & Treatment	-----	43 Page
<b>Warrantee Certificate</b>	-----	<b>44 Page</b>

# 1. BEFORE INSTALLATION

## Caution / Warning Marks

---



This mark warns the possibility to arrive death or serious injury in case of wrongly used.



This mark cautions the possibility to arrive serious human body injury or product lose in case of wrongly used.

---

## Copy Rights

1. All Right and Authority for this Manual is belonged to SEWHA CNM CO., LTD.
2. Any kinds of copy or distribution without permission of SEWHA CNM CO., LTD. will be prohibited.
3. This manual may be changed as the version is upgraded, without previous notice.

## Inquiries

If you have any kinds of inquiries for this model, please contact your local agent or Head Office.

Head Office : SEWHA CNM CO., LTD.

Website : <http://www.sewhacnm.co.kr>

Email : [sales@sewhacnm.co.kr](mailto:sales@sewhacnm.co.kr)

## 2. INTRODUCTION

### 2-1. Introduction

Thank you for your choice of this SI300 Industrial Digital Weighing Indicator.

This SI300 model is high-performance weighing Indicator.

Please review and learn this instruction Manual and enjoy your process efficiency with "SI 300" Weighing Indicator.



### 2-2. Cautions

1. Don't drop on the ground and avoid serious external damage on item.
2. Don't install under sunshine or heavy vibrated condition.
3. Don't install place where high voltage or heavy electric noise condition.
4. When you connect with other devices, please turn off the power of item.
5. Avoid from water damage.
6. For the improvement of function or performance, we can change item specification without previous notice or permission.
7. Item's performance will be up-dated continuously base on previous version's performance.

### 2-3. Features

1. SI 300 model is the standard 1/8 DIN SIZE and compact enough, so it is easy to install.
2. It has wide range of DC Input.
3. Front panel is covered with Polycarbonate film, strong against dust and water.
4. RS-422/485 serial port standard installed,

### 3. SPECIFICATION

#### 3-1 Specification

Content		Specification	
Performance	External Resolution	1/20,000	
	Internal Resolution	1/2,097,152 ( $\pm 1,048,576$ )	
	Input Sensitivity	0.1 $\mu$ V/V	
	Max. Signal Input Voltage	3.2 mV/V	
	Load cell Excitation	DC +5V	
	A/D Conversion Method	Sigma-Delta	
	Decimal Point	0, 0.0, 0.00, 0.000	
	Drift	Offset	10PPM/ $^{\circ}$ C
		Span	10PPM/ $^{\circ}$ C
	Linearity		0.001% of Full Scale
Analogue Sampling(sec)		60times / sec	
Environment	Operating Temperature Range	-10 $^{\circ}$ C ~ +40 $^{\circ}$ C [14 $^{\circ}$ F ~ 104 $^{\circ}$ F]	
	Operation Humidity Range	40% ~ 85% RH, Non-condensing	
Function	Calibration Mode	Test Weight Calibration Mode Simulation Calibration Mode	
	Display	7segment 6 digit, 1 inch Red Color FND	
	Key Pad	5EA Standard Key	
Comm	Serial Interface	Data Transference Command Mode Serial Printer Mode	
Power	AC FREE VOLTAGE ( AC 90 ~ 250V ) 50/60 Hz		
Size	190mm(W) x 124mm(H) x 122mm(D)	Weight : 2.0kg	

### 3-2. Front Panel






#### 3-2-1 Front Panel (Display / Key Pad)



#### 3-2-2. State Lamp




<b>STEADY</b>	When the weight is "STEADY", Lamp is ON.
<b>ZERO</b>	When the current weight is "ZERO", Lamp is ON.
<b>TARE</b>	"TARE" function is set, Lamp is ON.
<b>HOLD</b>	"HOLD" function is set, Lamp is ON.
<b>TxD</b>	When the Indicator transmits Serial communication data (Print data), Lamp is ON.
<b>RxD</b>	When the Indicator receives Serial communication data, Lamp is ON.

3-2-3. Key Operation

	<ol style="list-style-type: none"> <li>1. Normal Mode : Make Weight value as Zero. (F07, F08 setting)</li> <li>2. Calibration Mode : Cancel the value or move to previous step.</li> </ol>
	<ol style="list-style-type: none"> <li>1.Normal Mode : Set the TARE Function .(F09 setting) 1<sup>st</sup> input : "TARE", 2<sup>nd</sup> input : "TARE Reset" (When "HOLD" or weight value is ZERO, then this key doesn't work.)</li> <li>2.Calibration Mode : Move to left</li> <li>3.F-Function setting : Move to left</li> <li>4.Test Mode 1 : Analog value check mode</li> </ol>
	<ol style="list-style-type: none"> <li>1. To set the "HOLD" Function (refer F10) [1<sup>st</sup> input : "HOLD", 2<sup>nd</sup> input : "HOLD Reset" ]</li> <li>2.Calibration Mode : Move to right</li> <li>3.F-Function setting : Move to right</li> <li>3. Under "SETUP" Mode, Enter into the "Calibration" Mode.</li> <li>4.Test Mode 1 : Analog Variation value check mode</li> </ol>
	<ol style="list-style-type: none"> <li>1. Normal Mode : Print out (refer F38, F32)</li> <li>2.Calibration Mode :Increase set value</li> <li>3.F-Function setting : Increase set value</li> <li>4. Set up Mode : Enter Test Mode.</li> </ol> <p>※ If the printer is installed, under "F01-01 setting, when you press this key the current valued is increased. And the current weight is saved and print out, altogether. (Refer to CH.5-4)</p>
	<ol style="list-style-type: none"> <li>1. Press this key 4times, within 2secs, enter "SET-UP" mode.</li> <li>2.F-Function setting : Save the value go to next step</li> </ol>

●Setup Mode :It is a mode can SET UP the calibration, Function of SI300 .(refer to CH5. SET UP)

3-2-4. Hot key (with F key)

	<p>Continuous "TARE" setting (From the second TARE setting, use this key)</p>
	<p>If the Printer is installed, You can print out the "Grand-total data". (GRAND-total data can be checked though Print output).</p>
	<p>Manual delete the grand total data</p>

**Tip**

Max. accumulated weighing count : 999,999times  
Over 999,999times → return to "0" time  
Max. accumulated weight display : 999999999 (g, kg, ton)  
Over 999,999,999 (g, kg, ton) → return to "0" (g, kg, ton)

SI 300






Wall mounting / Desk type DIGITAL WEIGHT INDICATOR

### 3-3. Connector



<b>LOAD CELL</b>					<b>RS-232C</b>			<b>CURRENT LOOP</b>		<b>OFF</b>
EX+	EX-	SIG+	SIG-	SH	RxD	TxD	GND	C/L	C/L	<b>ON</b>

### 3-4. Composition


SI 300	AC Power Cable	Side Bolt	Terminal Pin	Manual
				



## 4. INSTALLATION


### 4-1. External Dimension & Cutting Size

External Dimension (unit: mm)



2

Cutting Size (unit : mm)



### 4-2. Installation Components



SI300

Connector (3EA)  
3P, 5P, 7P

Pin terminal(15EA)

User Manual

### 4-3 Load cell Installation

Load Cell Wire Connection (In case of SEWHACNM's Load cell)

It depends on the manufacturer of load cell, please check the specification.



-----Sewhacnm Co.,Ltd. Load cell & wire color----

※ Load cell wire color can be changed without prior notice.



**Caution**

Under set up the Load cell, if EXC+ and EXC- have a short circuit, It may cause damage in the indicator.(specially analogue board)

If you connect other wires to Load cell terminal wrongly, it may cause damage in the analogue board.

Before connecting the load cell cable you have to power off and be sure to connect the cable to the terminal correctly.

Do not weld near the load cells , Indicators or other devices.

#### Load Cell Installation

1. You can connect Max. 8pcs of same capacity Load cells at once. (350 Ω)
2. You have to make horizontal balance on the ground.
3. If you install more than 2pcs of load cells, use Summing box and adjust output signal difference as minimum. It can make wrong weighing process caused by each load cell's variation.
4. If there is some temperature difference around Load cell, it can cause wrong weight measurement.
5. Don't do Welding job or Arc discharge around installation place. But, there is no choice, please disconnect power cable and Load cell cable.
6. If you measure static electricity material, please make earth between down part and up part of Load cell.


## 5. SET-UP

### 5-1. Set up mode


This is the Menu which can set the all of the functions.

There may be some display differences between real and on the manual.

#### 5-1-1. Start "SET UP" Mode (Pass Word Not use)

Press  key four times within 2sec When "SET UP" is displayed, SETUP Mode is activated

#### 5-1-2. Start "SET UP" Mode (Pass Word Use – Refer F-function 95)





Press  key four times within 2sec If "P-W" displays, input 4 characters password.

If Password is right, "SETUP" Mode starts. If Password is wrong, it is back to weighing display.





















If you set password by "F95". "TEST" mode, you cannot start "SETUP" Mode without password. Please don't forget the pass word.

After starting "Calibration" mode, and "Test" mode, serial I/F will be closed.

- After initialization (F77) the password is  -  -  - .

#### • To Go Each Mode


Calibration	Weight Calibration	 key 4 times → (Pass word→)  → 
	Simulation Calibration	 key 4 times → (Pass word→)  →  → 
F-FUNCTION Mode		 key 4 times → (Pass word→) 
Test Mode	Analog Value	 key 4 times → (Pass word→)  → 
	Serial interface	 key 4 times → (Pass word→)  → 
	Key test	 key 4 times → (Pass word→)  → 

- Entering  means ESC/UPPER step, Entering  means SAVE/NEXT Step.

### ■ Adjusting “ZERO” Balance (Calibration)

Adjust weight balance between “Real weight” on the load cell (Weight Part) and “Displayed weight of Indicator”. When you replace LOAD CELL or Indicator, you have to Calibrate process once again.

(When you start calibration mode, TARE, HOLD & PRINT will be reset.)

 Before processing calibration, please warm up the indicator during 15 min to guarantee more preciseness.

#### Calibration Key



CANCEL/BACK

Move to left



Move to right


Increase set value


Save and Move  
to next step

## 5-2 Test Weight Calibration Mode (Using test weight)

### 5-2-1. Start Test Weight Calibration Mode






Under “SETUP” displays then Press  key.

When “CALIBR” displays, press  key,  
Then Test Weight Calibration Mode starts.

※ If you set password through “F95”, you have to input the pass word.



### 5-2-2. Setting “Capacity of weighing Scale”





After displaying "CAPA", input max capacity with keys & Press  key to save & move to next step.

**Tip** If you want that set Max capa is 1,000kg, then just input "1000".


## 5-2-3. "Decimal Point" and "Digit / Division" Value



After "DIVI" is displayed select Decimal point with  key.

Whenever pressing  key, decimal point will be changed.

Please stop at the optimal position. And select Division optimal division with  key.

Finally press  key to save and move to next step.

## Tip


Max. Decimal point will be 0.001, and digit can be selectable among 1, 2, 5, 10, 20, 50.

Digit and Decimal point must be fulfill the below condition.

- (Max. capacity value / division value) cannot be over than 20,000.

If this condition is not fulfilled, "Err-1" will be displayed and move back to Capacity setting mode.


## 5-2-4. Measure the "DEAD" Weight of Weighing Scale.



When "DEAD" displays, press



key, then indicator will calculate Dead weight of scale part automatically.



Indicator will search "DEAE weight" during 10~20 secs automatically to find the best condition.

※ Over than 1/10,000 resolution setting,


To guarantee the preciseness, DEAD weight calculation (CAL00~CAL09) will be operated twice.

## Tip


In this step, if there is some force or Vibration on scale part, these unstable conditions will be continued, "ErrorA" will be displayed, and "DEAD value" will not be calculated.

Under this condition, please remove the cause of force or vibration and process it again.


5-2-5. Input Test Weight value and Calculate SPAN value.



If "SPAN" is displayed, input "Test Weight" capacity and press **F** key.




If "UP" is displayed, please load "Test Weight" on the scale part and press **F** key.



Calculate Span value during 10 ~20 secs, automatically.

※ Over than 1/10,000 resolution setting,  
To guarantee the preciseness, Span calculation will be operated twice.



After calculation, span value will be displayed

on the display. Then press **F** key.

※This span value is not a weight value.

When "END" is displayed and calibration is completed.




### 5-3. Simulation Calibration Mode(Calibrate without Test weight)

With this "Simulation Calibration Mode" you can make simple calibration without any "TEST weight"


This calibration mode uses "Load cells' max capacity" and "Max. Output Rate(mV)", so the weight adjustment degree might be less than "Test weight Calibration".

The guaranteed resolution of this "Simulation Calibration" is 1/3,000.


#### 5-3-1. Simulation Calibration Mode Start



## 5-3-2. Setting "Capacity of Load Cell"



After "CAPA" displayed, Check Max. Capacity of Load cell.  
(refer the load cell label, or Test Report)


Input the Max. Capacity of Load cell. And press  key.


**Tip** In case of plural piece of load cells are installed, Please make sum of each load cell's capacity and make setting with Max. Capacity.


EX) There are 4pcs of load cells, and each load cell's Max. capa is1,000kg.

Then, total Max. Capacitywill be 4,000kg(1,000 x 4) and you have to input 4,000.


## 5-3-3. Setting "Digit / Division" value




After "DIVI" is displayed select Decimal point with  key.


Whenever pressing  key , decimal point will be changed.


Please stop at the optimal position. And select Division optimal division with  key.

Finally press  key to save and move to next step.

5-3-4. Measure the "DEAD Weight" of Weighing Scale.




"dEAd" is displayed. Please press  key with empty scale. Then the indicator starts to measure and find optimal "Dead weight value of Scale" automatically.




It takes 10sec or 20sec to get the best situation.

Over than 1/10,000 resolution setting,  
To guarantee the preciseness, dead weight calculation will be operated twice.


5-3-5. Input Max. Output ( Rated Output Voltage / mV)



Input the output value load cell  
Following fixed decimal point.



After "CAPA" displayed, Check Max. Capacity of Load cell.  
(refer the load cell label, or Test Report) . Press  key to save and move to next step.




If input wrong value, there will display "BAD", please go back to *Setting "Capacity of Load Cell"*.

After recheck the label of load cell and retry the process.


After displaying "mV", input Load cell Output Rate(mV), referring the load cell label. And press



key to save.



After finishing calculation, calculated "Span value" will be display with "DONE"



Now, the Simulation Calibration is done, press



key to complete the calibration process.

## Tip

In case of plural piece of load cells are connected, the rated output will be same as single load cell's. (Because plural load cells are connected with parallel connection, the sum of rated output voltage is same as single load cell's rated output)

※Due to some variation between "**State output rate**" and "**Real Output rate**" of load cell, there might be some weight difference after finishing calibration.


If you want to make more precise weighing process, please measure real output rate of load cell and input the measured value.

Then the weight measurement will be more precise than before.


### 5-4. F-FUNCTION Setting

Set-up means set the F-function and make optimal operation of SI 300 controller.

#### ■ Starting F-FUNCTION Mode



Press **F** key 4 times → Input Password → Displaying "SETUP" press **TARE** key.



## ■ F-Function List

General Function Setting ("●" Factory default set value)

Weighing Data Save Method selection			
F01	●	0	Non-Save Mode (Weight Data & weighing counter)
		1	Save Mode ( Weight Data & weighing counter)
Weight –Back up selection			
F02		0	Normal Mode
	●	1	Weight Back up Mode
Motion Band Range setting			
F03	05	01	This is set "Steady" acceptable range of weighing part. If there is vibration on weighing part, you can set this function and reduce the vibration effect on weighing process. 1 : Weak vibration ~ 99 : Strong Vibration
		∫ 99	
Zero Tracking Compensation Range setting			
F04	05	00	Due to external causes (Temperature, wind, and dust), there will be small weight difference, the Indicator will ignore the weight difference and display as Zero.
		∫ 99	
Auto Zero Range setting			
F05	00	00	Within the "Auto Zero" range, weighing part is steady, indicator will display current weight as "Zero" If the weighing part is not "Steady", indicator will display current weight. (Auto Zero Range : ± Set value + weight unit)
		∫ 99	
Digital Filter setting			
F06	04	0~40	0 (Weak vibration ) ~ 40 (Strong Vibration)
Zero key Operation mode selection			
F07		0	Activate only under "Steady" condition
	●	1	Always activate
Zero key Operation Range selection : (-) value is same to (+)			
F08		0	Activated within 2% of Max. Capacity
		1	Activated within 5% of Max. Capacity
	●	2	Activated within 10% of Max. Capacity
		3	Activated within 20% of Max. Capacity

		4	Activated within 50% of Max. Capacity
		5	Activated within 100% of Max. Capacity
		6	There is no limit of Zero key operation range.
<b>※ CAUTION : If setting over than 10%, The display weight could be over than Load cell input signal or Max. Capacity and it may display "CELL-Err" or incorrect weight value.</b>			
<b>Tare key Operation Range selection : (-) value is same to (+)</b>			
<b>F09</b>		0	Activated within 10% of Max. Capacity
		1	Activated within 20% of Max. Capacity
	●	2	Activated within 50% of Max. Capacity
		3	Activated within 100% of Max. Capacity
<b>"Hold" Mode selection</b>			
<b>F10</b>	●	0	Peak Hold : Measure Max. weight value and hold on display.
		1	Sample Hold : Hold current weight until "Hold Reset"
		2	Average Hold : Hold average value (Refer F-F50)
<b>"STEADY" condition check time setting</b>			
<b>F11</b>	3	0 ┌ 9	During the set time period, estimate weighing part's "STEADY" condition and display. If you set small value, indicator will take "STEADY" fast, if you set value, indicator will take "STEADY" slow. ( 0.5sec per set value)
<b>Display Up-Date speed setting</b>			
<b>F12</b>	●	1	60/sec
		2	30/sec
		3	20/sec
		4	15/sec
		5	10/sec
		6	6/sec
		7	3/sec
		8	2/sec
		9	1/sec
<b>Weight Display selection under "Unpass / OverLoad" condition</b>			
<b>F13</b>		0	Not Display Weight (just "UNPASS" or "-OL-" is displayed)
	●	1	Display Weight (with a flash)

Equipment No. setting – ID No.setting			
<b>F18</b>	01	01~99	ID No. setting with No. key. (01~99 settable)

### ■ Communication Mode Setting

Parity Bit selection Mode					
<b>F30</b>	<input checked="" type="radio"/>	0	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Non)
	<input type="radio"/>	1	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)
	<input type="radio"/>	2	DATA Bit (8 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)
	<input type="radio"/>	3	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Non)
	<input type="radio"/>	4	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Odd)
	<input type="radio"/>	5	DATA Bit (8 Bit)	STOP Bit (2 Bit)	Parity Bit (Even)
	<input type="radio"/>	6	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Odd)
	<input type="radio"/>	7	DATA Bit (7 Bit)	STOP Bit (1 Bit)	Parity Bit (Even)
	<input type="radio"/>	8	DATA Bit (7 Bit)	STOP Bit (2 Bit)	Parity Bit (Odd)
	<input type="radio"/>	9	DATA Bit (7 Bit)	STOP Bit (2 Bit)	Parity Bit (Even)
Serial Communication Speed selection					
<b>F31</b>	<input type="radio"/>	0	2,400bps		
	<input type="radio"/>	1	4,800bps		
	<input checked="" type="radio"/>	2	9,600bps		
	<input type="radio"/>	3	14,400bps		
	<input type="radio"/>	4	19,200bps		
	<input type="radio"/>	5	28,800bps		
	<input type="radio"/>	6	38,400bps		
	<input type="radio"/>	7	57,600bps		
	<input type="radio"/>	8	76,800bps		
	<input type="radio"/>	9	115,200bps		
DATA Transference Method selection					
<b>F32</b>	<input type="radio"/>	0	Simplex Mode / Stream Mode		
	<input checked="" type="radio"/>	1	Duplex Mode / Command Mode		
	<input type="radio"/>	2	Print Mode		
"Check-Sum" detection selection (Under F32-01 setting, only)					
<b>F34</b>	<input checked="" type="radio"/>	0	Check-Sum Not Use		
	<input type="radio"/>	1	Check-Sum Use		
Under Stream Mode select the way transmit data protocol/frame (basic port)					






F35	<input checked="" type="radio"/>	0	Transmit by Protocol
	<input type="radio"/>	1	Transmit by frame (in case of using specific utility)
<b>Caution : In case of "Transmit by frame" &amp; under 14,400bps setting(F31), the speed of system will be slow.</b>			
<b>DATA Transference Mode selection (Under F32-00 setting, only)</b>			
F36	<input checked="" type="radio"/>	0	Always
	<input type="radio"/>	1	Single time data transference, Whenever the weight is steady over Empty range.
	<input type="radio"/>	2	Single time data transference, at first steady point, over Empty range.
	<input type="radio"/>	3	Data transference, Whenever "Print" key input
<b>DATA Transference Format selection (Under F32-00 setting, only)</b>			
F37	<input checked="" type="radio"/>	0	Format 1 (recommended when use external display)
	<input type="radio"/>	1	Format 2. (Format 1 + ID No.)
	<input type="radio"/>	2	Format 3. (recommended when connecting to PLC or PC)
	<input type="radio"/>	3	CAS Format
<b>Print Mode selection (Under F32-02 setting, only)</b>			
F38	<input checked="" type="radio"/>	0	Manual Print : Whenever "Print" key input.
	<input type="radio"/>	1	Auto print (at the first Steady point over "EMPTY" range or Whenever "Print" key input.)
	<input type="radio"/>	2	Auto print (Whenever Steady status at over "EMPTY" range or Whenever "Print" key input.)

### ■ Print Mode Setting

<b>Weight Unit selection</b>			
F41	<input checked="" type="radio"/>	0	Kg
	<input type="radio"/>	1	g
	<input type="radio"/>	2	t
<b>Print Format selection</b>			
F42	<input checked="" type="radio"/>	0	<b>Continuous Print</b> - Serial No. and Weight will be printed continuously.
	<input type="radio"/>	1	<b>Single Print</b> - Date, Time, S/N, ID No. Weighing Data will be print
<b>SUB/GRAND Total Data Delete selection</b>			
F44	<input checked="" type="radio"/>	0	Not deleted (= manual Delete mode)
	<input type="radio"/>	1	Automatically Deleted.-After print out SBU/GRAND Total.

Paper Withdraw Rate setting (After SUB/GRAND Total Print)			
F45	3	0~9	Whenever set value increased as 1, then 1 line will be added.
Paper Withdraw Rate setting (After Continuous/Single Print)			
F46	3	0~9	Whenever set value increased as 1, then will be added.
Printing Language Selection			
F47	<input checked="" type="radio"/>	0	KOREAN
	<input type="radio"/>	1	ENGLISH
Minus(-) symbol Print selection			
F49	<input checked="" type="radio"/>	0	Print minus(-) symbol, if the weight is minus(-).
	<input type="radio"/>	1	Ignore minus(-) symbol
Set time of "Average Hold"			
F50	3	0~9	When setting "Average Hold", set the time. (unit : sec) ※Automatic Hold Rest , After set time.


Other Setting Mode


EMPTY Range setting		
F80	10	<p>You can set "EMPTY" Range.</p> <p>Ex) "0" setting : When Net Zero, "Zero" status lamp is ON.</p> <p>"200" setting : Under "200", "Zero" Status lamp is ON.</p>
TIME(H,M,S) Check / Change (every 24Hours)		
F90		Check Current DATE data or you can Change to new date
TIME Check / Change		
F91		Check Current TIME data or you can Change to new time
SETUP Mode Password Key Setting / Change		
		<p><b>Setting the password</b></p> <div style="display: flex; justify-content: space-around;">   </div> <p>1) When "1" displays, input 4 numbers</p> <p>2) If "2" display, input the 4 numbers once more. (recheck the password)</p> <hr/> <p><b>Change the password</b></p>  <p>If "P-W" display, input the previous saved password . And set the "FFFF" as New password.</p> <hr/> <p><b>Deactivate Lock setting</b></p> <p><b>Caution</b> If you set password four times of <b>FFFF</b> (5555), it is unlocked. After initialization (F77) the default password is <b>FFFF</b></p> <p>When setting password you cannot start "SETUP" mode without password, do not forget your password.</p>
Program & Hard ware Version Check		
F98		<p>Check the Program &amp; Hard ware version</p> <p>Ex) "100 1.04" means H/W : ver.1.00 &amp; S/W : ver.1.04</p>


5-5. Test Mode








Before starting the TEST mode, please remove operating devices.



Under "SETUP" mode, press  key.



TEST MODE 1


TEST MODE 1				
				
ESC / BACK	Analog value Check Mode	Analog Variation Value Check Mode	Key/Digital Input Check Mode	Standard serial port test mode

**Tip**






If there is no change although pressing keys or loading some force on/in weighing part, it may be something wrong with load cell, cable, connector or A/D board

5-5-1. Analog Check Mode



Under this mode, you can check analogue value to real digital value through Display. The last digital value can be fluctuated



Displaying  
1~100,000




Displaying  
10~1,000,000






Displaying  
100~10,000,000

5-5-2. Analogue Value Check Mode



Under this mode, you can check the variation degree of analogue value .



Zero Key




Displaying  
10~1,000,000




Displaying  
100~10,000,000

5-5-3. Key / Digital input Test Mode




Under this mode, you can test Key input and Digital Key input test

Whenever pressing key pad or plus to digital input terminal, the matched No. will be displayed on the each position.




First display position is for key pad input



Second display position is for digital input

4) Serial Interface Test Mode.




Connect with PC or other devices through serial interface and check the transference and receipt.

At the normal operation, display will be blinked.

To test this mode, please use "TESTING Protocol".

※ TESTING PROTOCOL.



※ If you send "Testing protocol" from PC to Indicator, at the normal operation Display will blink.

## 6. INTERFACE

### 6-1. Serial Interface

#### 6-1-1. Serial Interface (RS-232C)




RxD ----- 3  
TxD ----- 2  
GND ----- 5



#### 6-1-2. Current Loop




극성 없음




Serial communication interface is sensitive to electric noise.  
Install isolated place from Power cable or other electric cables and wires,  
and please use shielded cable for better performance.

6-1-4. Data Format


1. Data Format1 : ID Number is not be transferred.(Refer "FUNCTION 37/F67-00" setting)



2. Data Format2 : ID Number + Data Transference (Refer F-function 37-01, F18)




3. Data Format3 : ID Number + State (F37-03 setting)



Header1	Header2
O : OVER	G : Gross weight
S : STEADY	N : Net weight
U : UNSTABLE	



4. CAS Format (22byte)




LAMP DISPLAY

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1	0	1	1	1	1	1	1
1	STEADY	1	Hold	Print	Gross Weight	TARE	ZERO

Header1	Header2
OL : OVER LOAD	NT : GROSS weight
ST : STEADY	GS : Net weight
US : UNSTEADY	

6-1-5. Command Mode (F32-01 setting)

Under "Command Mode", Indicator will recognize the receipt of Order based on 02h(Header) and 03h(END) signal, and transfers ACK/ NAK).



※Although wrong value is transmitted, the communication format is matched, then ACK is transmitted.

Read Command

1.Current Weight data																																																																																								
<b>ASCII :</b> STX ID(2Byte) RCWT ETX	<b>HEX :</b> 02 30 31 52 43 57 54 03																																																																																							
<b>SI 300 response</b>	STX ID RCWT <b>State1(1byte) State2(1byte) P decimal point(1byte) +/- (1byte) Current weight(7byte) unit(2byte) ETX</b>																																																																																							
	<b>State1 : O(Over load) , S(Steady), U(Unsteady)</b> <b>State2 : N(Net weight), G(Gross weight), P+No. : decimal point number</b>																																																																																							
Ex) Steady(S), TARE not used(N), 0.000kg <u>State1, State2, Decimal point</u>																																																																																								
<table border="0"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>C</b></td><td><b>W</b></td><td><b>T</b></td><td><b>S</b></td><td><b>N</b></td><td><b>P</b></td><td><b>3</b></td><td><b>+</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>k</b></td><td><b>g</b></td><td><b>ETX</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>43h</td><td>57h</td><td>54h</td><td>53h</td><td>4Eh</td><td>50h</td><td>33h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>6Bh</td><td>67h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>C</b>	<b>W</b>	<b>T</b>	<b>S</b>	<b>N</b>	<b>P</b>	<b>3</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>k</b>	<b>g</b>	<b>ETX</b>	02h	30h	31h	52h	43h	57h	54h	53h	4Eh	50h	33h	2Bh	30h	30h	30h	30h	30h	30h	30h	30h	6Bh	67h	03h																																									
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>C</b>	<b>W</b>	<b>T</b>	<b>S</b>	<b>N</b>	<b>P</b>	<b>3</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>k</b>	<b>g</b>	<b>ETX</b>																																																																		
02h	30h	31h	52h	43h	57h	54h	53h	4Eh	50h	33h	2Bh	30h	30h	30h	30h	30h	30h	30h	30h	6Bh	67h	03h																																																																		
2. Indicator memory data																																																																																								
<b>ASCII :</b> STX ID(2Byte) RCWD ETX	<b>HEX :</b> 02 30 31 52 43 57 44 03																																																																																							
<b>SI 300 response</b>	STX ID RCWD P decimal point(1byte)DATE(6byte) TIME(6byte) the no. of weighing (6byte) +/- TARE(7Byte) +/- current weight(7byte) unit(2byte) ETX																																																																																							
	Ex) DATE : Aug 12 <sup>th</sup> ,2009, TIME : 12:00:00, the no. of weighing : 10, TARE : 2.000kg, current weight : 3.000kg <u>decimal point</u>																																																																																							
<table border="0"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>C</b></td><td><b>W</b></td><td><b>D</b></td><td><b>P</b></td><td><b>3</b></td><td><b>0</b></td><td><b>9</b></td><td><b>0</b></td><td><b>8</b></td><td><b>1</b></td><td><b>2</b></td><td><b>1</b></td><td><b>2</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>43h</td><td>57h</td><td>44h</td><td>50h</td><td>33h</td><td>30h</td><td>39h</td><td>30h</td><td>38h</td><td>31h</td><td>32h</td><td>31h</td><td>31h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td> </tr> <tr> <td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>1</b></td><td><b>0</b></td><td><b>+</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>2</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>+</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>3</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>ETX</b></td> </tr> <tr> <td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>31h</td><td>30h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>2Bh</td><td>32h</td><td>30h</td><td>30h</td><td>33h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>C</b>	<b>W</b>	<b>D</b>	<b>P</b>	<b>3</b>	<b>0</b>	<b>9</b>	<b>0</b>	<b>8</b>	<b>1</b>	<b>2</b>	<b>1</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	02h	30h	31h	52h	43h	57h	44h	50h	33h	30h	39h	30h	38h	31h	32h	31h	31h	30h	30h	30h	30h	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>3</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	30h	30h	30h	30h	31h	30h	2Bh	30h	30h	30h	32h	30h	30h	30h	2Bh	32h	30h	30h	33h	30h	30h	30h	03h
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>C</b>	<b>W</b>	<b>D</b>	<b>P</b>	<b>3</b>	<b>0</b>	<b>9</b>	<b>0</b>	<b>8</b>	<b>1</b>	<b>2</b>	<b>1</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>																																																																					
02h	30h	31h	52h	43h	57h	44h	50h	33h	30h	39h	30h	38h	31h	32h	31h	31h	30h	30h	30h	30h																																																																				
<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>3</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																																																																		
30h	30h	30h	30h	31h	30h	2Bh	30h	30h	30h	32h	30h	30h	30h	2Bh	32h	30h	30h	33h	30h	30h	30h	03h																																																																		
3. Grand Total data																																																																																								
<b>ASCII :</b> STX ID(2Byte) RGRD ETX	<b>HEX :</b> 02 30 31 52 43 57 44 03																																																																																							
<b>SI 300 response</b>	STX ID RGRD P decimal point(1byte) the no. of weighing (6byte) Accumulated weight(10byte) unit(2byte) ETX																																																																																							
	Ex) the no. of weighing : 10 , Accumulated Weight : 10.000kg <u>decimal point</u>																																																																																							
<table border="0"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>G</b></td><td><b>R</b></td><td><b>D</b></td><td><b>P</b></td><td><b>3</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>1</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>1</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>ETX</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>47h</td><td>52h</td><td>44h</td><td>50h</td><td>33h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>31h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>30h</td><td>31h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>G</b>	<b>R</b>	<b>D</b>	<b>P</b>	<b>3</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	02h	30h	31h	52h	47h	52h	44h	50h	33h	30h	30h	30h	30h	31h	30h	30h	30h	30h	30h	31h	30h	30h	30h	03h																																							
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>G</b>	<b>R</b>	<b>D</b>	<b>P</b>	<b>3</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																																																																	
02h	30h	31h	52h	47h	52h	44h	50h	33h	30h	30h	30h	30h	31h	30h	30h	30h	30h	30h	31h	30h	30h	30h	03h																																																																	

4.Finished Weight data																																				
<b>ASCII :</b> STX ID(2Byte) RFIN ETX	<b>HEX:</b> 02 30 31 52 46 49 4E 03																																			
<b>SI 300 response</b>	STX ID RFIN P decimal point(1byte) +/- Finished weight(7byte) ETX																																			
Ex) Finished weight : 2.000kg      decimal point																																				
<table style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>F</b></td><td><b>I</b></td><td><b>N</b></td><td><b>P</b></td><td><b>3</b></td><td><b>+</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>2</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>ETX</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>46h</td><td>49h</td><td>4Eh</td><td>50h</td><td>33h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>F</b>	<b>I</b>	<b>N</b>	<b>P</b>	<b>3</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	02h	30h	31h	52h	46h	49h	4Eh	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>F</b>	<b>I</b>	<b>N</b>	<b>P</b>	<b>3</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																				
02h	30h	31h	52h	46h	49h	4Eh	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h																			
5. Current time Data																																				
<b>ASCII :</b> STX ID(2Byte) RTIM ETX	<b>HEX:</b> 02 30 31 52 54 49 4D 03																																			
<b>SI 300 response</b>	STX ID RTIM Current Time(6byte) ETX																																			
Ex) Time : 12:00:00																																				
<table style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>T</b></td><td><b>I</b></td><td><b>M</b></td><td><b>1</b></td><td><b>2</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>ETX</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>54h</td><td>49h</td><td>4Dh</td><td>31h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>T</b>	<b>I</b>	<b>M</b>	<b>1</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	02h	30h	31h	52h	54h	49h	4Dh	31h	32h	30h	30h	30h	03h									
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>T</b>	<b>I</b>	<b>M</b>	<b>1</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																								
02h	30h	31h	52h	54h	49h	4Dh	31h	32h	30h	30h	30h	03h																								
6. Current date Data																																				
<b>ASCII :</b> STX ID(2Byte) R DAT ETX	<b>HEX :</b> 02 30 31 52 44 41 54 03																																			
<b>SI 300 response</b>	STX ID R DAT Current Date(6byte) ETX																																			
Ex) Date : Aug 12 <sup>th</sup> ,2009																																				
<table style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>D</b></td><td><b>A</b></td><td><b>T</b></td><td><b>0</b></td><td><b>9</b></td><td><b>0</b></td><td><b>8</b></td><td><b>1</b></td><td><b>2</b></td><td><b>ETX</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>41h</td><td>41h</td><td>54h</td><td>30h</td><td>39h</td><td>30h</td><td>38h</td><td>31h</td><td>32h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>D</b>	<b>A</b>	<b>T</b>	<b>0</b>	<b>9</b>	<b>0</b>	<b>8</b>	<b>1</b>	<b>2</b>	<b>ETX</b>	02h	30h	31h	52h	41h	41h	54h	30h	39h	30h	38h	31h	32h	03h								
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>D</b>	<b>A</b>	<b>T</b>	<b>0</b>	<b>9</b>	<b>0</b>	<b>8</b>	<b>1</b>	<b>2</b>	<b>ETX</b>																								
02h	30h	31h	52h	41h	41h	54h	30h	39h	30h	38h	31h	32h	03h																							
7. Tare data																																				
<b>ASCII :</b> STX ID(2Byte) RTAR ETX	<b>HEX :</b> 02 30 31 52 54 41 52 03																																			
<b>SI 300 response</b>	STX ID RTAR P decimal point(1byte) +/- (1byte) TARE value(7byte) ETX																																			
Ex) TARE : 2.000kg      decimal point																																				
<table style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td><b>STX</b></td><td><b>ID</b></td><td><b>R</b></td><td><b>T</b></td><td><b>A</b></td><td><b>R</b></td><td><b>P</b></td><td><b>3</b></td><td><b>+</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>2</b></td><td><b>0</b></td><td><b>0</b></td><td><b>0</b></td><td><b>ETX</b></td> </tr> <tr> <td>02h</td><td>30h</td><td>31h</td><td>52h</td><td>54h</td><td>41h</td><td>52h</td><td>50h</td><td>33h</td><td>2Bh</td><td>30h</td><td>30h</td><td>30h</td><td>32h</td><td>30h</td><td>30h</td><td>30h</td><td>03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>R</b>	<b>T</b>	<b>A</b>	<b>R</b>	<b>P</b>	<b>3</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	02h	30h	31h	52h	54h	41h	52h	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h
<b>STX</b>	<b>ID</b>	<b>R</b>	<b>T</b>	<b>A</b>	<b>R</b>	<b>P</b>	<b>3</b>	<b>+</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																				
02h	30h	31h	52h	54h	41h	52h	50h	33h	2Bh	30h	30h	30h	32h	30h	30h	30h	03h																			

## Tip

Recommended Interval of READ COMMAND is min.60ms, 70ms is recommended, under 9600bps setting.

Min.60ms is required between each Read Command(under RCWD)

Min. interval is changed when data's length & speed are changed.

Min Interval : 20ms under 2400bps(RCWD)

Min Interval : 40ms under 115200bps (RCWD)

## ■Write Command

Zero (same as "ZERO" key)																												
<b>ASCII :</b> STX ID(2Byte) WZER ETX	<b>HEX:</b> 02 30 31 57 5A 45 52 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
TARE																												
<b>ASCII :</b> STX ID(2Byte) WTAR ETX	<b>HEX:</b> 02 30 31 57 54 41 52 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
TARE reset																												
<b>ASCII :</b> STX ID(2Byte) WTRS ETX	<b>HEX:</b> 02 30 31 57 54 52 53 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
HOLD																												
<b>ASCII :</b> STX ID(2Byte) WHOL ETX	<b>HEX:</b> 02 30 31 57 48 4F 4C 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
HOLD reset																												
<b>ASCII :</b> STX ID(2Byte) WHRS ETX	<b>HEX:</b> 02 30 31 57 48 52 53 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
PRINT																												
<b>When transfer format, "F46 : plus line" and "F34 : checksums are not applied.</b>																												
<b>ASCII :</b> STX ID(2Byte) WPRT ETX	<b>HEX:</b> 02 30 31 57 50 52 54 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
PRINT grand total																												
<b>ASCII :</b> STX ID(2Byte) WGPR ETX	<b>HEX:</b> 02 30 31 57 47 50 52 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
Delete grand total																												
<b>ASCII :</b> STX ID(2Byte) WGTC ETX	<b>HEX:</b> 02 30 31 57 47 54 43 03																											
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
Date setting																												
<b>ASCII :</b> STX ID(2Byte) WDAT current DATE (6byte) ETX																												
Ex) Date : Aug 12 <sup>th</sup> ,2009																												
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>STX</th> <th>ID</th> <th>W</th> <th>D</th> <th>A</th> <th>T</th> <th>0</th> <th>9</th> <th>0</th> <th>8</th> <th>1</th> <th>2</th> <th>ETX</th> </tr> </thead> <tbody> <tr> <td>02h</td> <td>30h</td> <td>31h</td> <td>57h</td> <td>44h</td> <td>41h</td> <td>54h</td> <td>30h</td> <td>39h</td> <td>30h</td> <td>38h</td> <td>31h</td> <td>32h</td> <td>03h</td> </tr> </tbody> </table>		STX	ID	W	D	A	T	0	9	0	8	1	2	ETX	02h	30h	31h	57h	44h	41h	54h	30h	39h	30h	38h	31h	32h	03h
STX	ID	W	D	A	T	0	9	0	8	1	2	ETX																
02h	30h	31h	57h	44h	41h	54h	30h	39h	30h	38h	31h	32h	03h															
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											

Time setting																												
<b>ASCII</b> : STX ID(2Byte) WTIM Time (6byte)ETX																												
Ex) Time : 12:00:00																												
<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 0 5px;"><b>STX</b></td> <td style="padding: 0 5px;"><b>ID</b></td> <td style="padding: 0 5px;"><b>W</b></td> <td style="padding: 0 5px;"><b>T</b></td> <td style="padding: 0 5px;"><b>I</b></td> <td style="padding: 0 5px;"><b>M</b></td> <td style="padding: 0 5px;"><b>1</b></td> <td style="padding: 0 5px;"><b>2</b></td> <td style="padding: 0 5px;"><b>0</b></td> <td style="padding: 0 5px;"><b>0</b></td> <td style="padding: 0 5px;"><b>0</b></td> <td style="padding: 0 5px;"><b>0</b></td> <td style="padding: 0 5px;"><b>ETX</b></td> </tr> <tr> <td style="padding: 0 5px; border: 1px solid black;">02h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">31h</td> <td style="padding: 0 5px; border: 1px solid black;">57h</td> <td style="padding: 0 5px; border: 1px solid black;">54h</td> <td style="padding: 0 5px; border: 1px solid black;">49h</td> <td style="padding: 0 5px; border: 1px solid black;">4Dh</td> <td style="padding: 0 5px; border: 1px solid black;">31h</td> <td style="padding: 0 5px; border: 1px solid black;">32h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>W</b>	<b>T</b>	<b>I</b>	<b>M</b>	<b>1</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	02h	30h	31h	57h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h
<b>STX</b>	<b>ID</b>	<b>W</b>	<b>T</b>	<b>I</b>	<b>M</b>	<b>1</b>	<b>2</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																
02h	30h	31h	57h	54h	49h	4Dh	31h	32h	30h	30h	30h	30h	03h															
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											
Change S/N																												
<b>ASCII</b> : STX ID(2Byte) WSNO S/N(6byte)ETX																												
Ex) S/N is changed to 100																												
<table style="margin: auto; border-collapse: collapse;"> <tr> <td style="padding: 0 5px;"><b>STX</b></td> <td style="padding: 0 5px;"><b>ID</b></td> <td style="padding: 0 5px;"><b>W</b></td> <td style="padding: 0 5px;"><b>S</b></td> <td style="padding: 0 5px;"><b>N</b></td> <td style="padding: 0 5px;"><b>O</b></td> <td style="padding: 0 5px;"><b>O</b></td> <td style="padding: 0 5px;"><b>O</b></td> <td style="padding: 0 5px;"><b>O</b></td> <td style="padding: 0 5px;"><b>1</b></td> <td style="padding: 0 5px;"><b>0</b></td> <td style="padding: 0 5px;"><b>0</b></td> <td style="padding: 0 5px;"><b>ETX</b></td> </tr> <tr> <td style="padding: 0 5px; border: 1px solid black;">02h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">31h</td> <td style="padding: 0 5px; border: 1px solid black;">57h</td> <td style="padding: 0 5px; border: 1px solid black;">53h</td> <td style="padding: 0 5px; border: 1px solid black;">4Eh</td> <td style="padding: 0 5px; border: 1px solid black;">4Fh</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">31h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">30h</td> <td style="padding: 0 5px; border: 1px solid black;">03h</td> </tr> </table>		<b>STX</b>	<b>ID</b>	<b>W</b>	<b>S</b>	<b>N</b>	<b>O</b>	<b>O</b>	<b>O</b>	<b>O</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>ETX</b>	02h	30h	31h	57h	53h	4Eh	4Fh	30h	30h	30h	31h	30h	30h	03h
<b>STX</b>	<b>ID</b>	<b>W</b>	<b>S</b>	<b>N</b>	<b>O</b>	<b>O</b>	<b>O</b>	<b>O</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>ETX</b>																
02h	30h	31h	57h	53h	4Eh	4Fh	30h	30h	30h	31h	30h	30h	03h															
<b>SI 300 response</b>	normal: STX ID ACK ETX error: STX ID NAK ETX																											



**Tip** Recommended Comm. Interval of WRITE COMMAND is Min. 100ms.  
 Comm. Interval of WPRT is Min.300ms  
 You have to guarantee Min. 100ms interval between two different commands.  
 Response for WPRT will be output through Print Port, set by F32-0.

■ Command Mode Example



READ COMMAND

Ex.) Current Weight Command(RCWT), ID No. : 01, Current Weight : 7,000kg

1) P.C Read Command Format (STX ID NO. RCWT ETX) "Check-sum" not used.



2) When PC requests to Indicator, Format(STX ID RCWT ETX) CHCEK SUM is used.




**WRITE COMMAND**


Ex) SP1 Setting Command, ID No : 01, New SP1 Set value : 0.600kg

1) PC Write command format (STX ID WPR1 000.600 ETX) "CHECK SUM" not use.


PC transmits to SI300



SI300 Response to PC




Normal operation




Incorrect operation

1) PC Write command format (STX ID WPR1 000.600 ETX) "CHECK SUM" use.


PC transmits to SI300



SI300 Response to PC



Normal operation



Incorrect operation

**Tip**

All Read/Write command must be use "HEX CODE"..

**How to Calculate Check sum.**

- Sum the value from "STX" to "ETX" and converts to ASCII(2byte) and transfer.

Convert the Sum value(HEX) to ASCII and transmit(28byte) .

ex) The sum HEX value from STX to ETX(02,30,31,52,43,57,54,03) is 1A6h.

Then, divide 1A6h by 100h(1A6h/100h). the rest of result is A6h.

Calculated remainder value is A6h, then convert A6h to ASCII, 41(A), 36(6), and transfer.

**6-2 Serial Print (F32-02 setting) – RS-232 Serial Interface.**

It can be connected with all kinds of Serial interface printer, but the printing format is already programmed and fixed with SE7200/7300 model.

**6-2-1. Printing Format**

Using the RS-485 or 422 interface, please use convertor and converts to RS-232 and connect with Serial printer.

If you use RS-232 serial interface, connect directly without any convertor.

**English Format (F47-01)**

```

=====
DATE :          2009-05-10
TIME :          18:00:10
COUNT          WEIGHT
   1            + 1.330kg
   2            + 5.350kg
   3            + 1.380kg
   4            + 2.330kg
    
```

**Continuous Print Format(F42-00)**

```

=====
DATE :          2009-05-10
TIME :          18:00:10
COUNT          WEIGHT
   2            + 5.350kg

=====
DATE :          2009-05-10
TIME :          18:00:10
COUNT          WEIGHT
   3            + 1.280kg
    
```

**Single Print Format(F42-01)**

```

=====
TOTAL
DATE :          2009-05-10
TIME :          18:00:10
COUNT :        10
TOTAL WEIGHT :  258.145kg
=====
TOTAL DELETE
=====
    
```

**Grand Total Print  
(Grand Total Print delete setting, F44-01)**



## 7. Error & Treatment

### 7-1. Load Cell Installation

Error	Cause	Treatment	Remarks
Weight Value is unstable	1) Load cell broken 2) Load cell isolation resistance error 3) Weighing part touches other devices or some weight is on the weighing part 4) Summing Board Error	1) Measure input/output resistance of Load cell. 2) Measure Load cell isolation resistance	1) Input Resistance of "EX+" and "EX-" is about 350Ω~450Ω. 2). Output Resistance of "EX-" and "EX+" is about 350Ω. 3). Isolate Resistance is more than 100Ω
Weight Value is increased regular rate, but not return to "Zero"	1) Load cell Error 2) Load cell connection Error	1) Check Load cell connection 2) Measure Load cell Resistance	
Weight Value is increased to under Zero	Load cell Output wire (SIG+, SIG-) is switched	Make wire correction	
"UN PASS" display	Load cell broken or Indicator connection Error	Load cell Check Load cell connection Check	
	Power was "ON" when some weight is on the load cell.	Remove weight on the Load cell	
"OL" or "UL" display(Over Load)	1) Load cell broken or Indicator connection Error 2) Loading over than Max. Capacity	1) Load cell Check 2) Load cell connection Check 3) Remove over loaded weight	


## 7-2. Calibration Process

Display	Cause	Treatment
<i>Err01</i>	When Max.capacity/digit value is over 20,000	Re-input the Max. Capacity, less than 20.00 (Max. Capacity / Digit)
<i>Err04</i>	Standard weight value is over than Max. Capacity	Re-input Standard weight value with Number keys, under Max. Capacity
<i>Err05</i>	Standard weight value is less than 10% of Max. Capacity	Re-input Standard weight value with Number keys, more than 10% of Max. Capacity
<i>Err06</i>	<ol style="list-style-type: none"> <li>1. Amp. Gain is too big</li> <li>2. Sig+ and Sig- wire connection error</li> <li>3. Test weight is not loaded</li> </ol>	<p>Check standard weight's weight with set value.</p> <p>If there is difference between set value and real weight, please re-input the value (set value is too small)</p>
<i>Err07</i>	<ol style="list-style-type: none"> <li>1. Amp. Gain is too small</li> <li>2. Sig+ and Sig- wire connection error</li> <li>3. Test weight is not loaded</li> </ol>	<p>Check standard weight's weight with set value.</p> <p>If there is difference between set value and real weight, please re-input the value (set value is too big)</p>
<i>Err08</i>	Under "F-function" model, set value is "N.A"	Check the correct value and re-input
<i>Err-A</i>	When there is continuous vibration on the weighing part,, indicator cannot process calibration any more.	<ul style="list-style-type: none"> <li>- Find vibration cause and remove</li> <li>- Load cell check</li> <li>- Load cell cable and connecting condition check</li> </ul>

## 7-3. Digital Weighing Indicator

Display	Cause	Treatment
<p>"CELL - Er"</p> <p>or</p> <p>"OVER"</p>	<p>1. Load cell Error</p> <p>2. Load cell cable Error</p> <p>3. Load cell connection Error</p> <p>4. A/D Board Error</p> <p>5. If Analogue value is over 1,040,000.</p> <p>※ When weigh "-" value, If it is over set max capa, "OVER" is displayed.</p> <p>Ex) Even though set max capa is "100" and it is over "-100", "OVER" is displayed.</p>	<p>1. Under "TEST" mode 1, check analogue value. If you cannot get any analogue value or there is no change although adding load, please check load cell, load cell cable, connection conditions first.</p> <p>2. Replace another load cell, and check the indicator condition. If you have same problem, please replace new indicator and check A/D board error.</p> <p>3. Try to connect the indicator's A/D with the other indicator.</p> <p>4. Check the power and connection of terminal.</p>
"UNPASS"	<p>1. Power is ON, when some materials are on weighing part.</p> <p>※ Under "Normal Mode", if there are more than 20% loading of Max. capacity, "Un-Pass" display will be appeared and indicator will stay until removing the load.</p> <p>※ Setting Back-up mode it can memory empty value, and it becomes set value without displaying "Un-pass")</p>	<p>1. If you set "Normal Mode", please check weighing part empty or not before turn on the power. If there are some materials in/on weighing part, please remove those materials and turn on the power.</p> <p>2. Please try to set F02-01(Back-up) mode so that the indicator can remember first empty value.</p>
"SET"	<p>When Power is on, "SET" displays. It means EEPROM has some problem.</p>	Please contact the distributor or Head Office.
"HALLT"	H/W has some problem.	
"E-Err"	The dead Battery	

※ Under "CELL - Er", Zero key, Tare key, Hold key and print key will not be activated.

<b>WARRANTEE CERTIFICATION</b>	
<p>This product is passed "Sewhacnm's strict quality test.</p> <p>If there is defect of manufacturing or abnormal detection within warrantee period, please contact our Agent or Distributor with this Warrantee certificate.</p> <p>Then, we will repair or replace free of charge.</p>	
<b>WARRANTEE CLAUSE</b>	
<p><b>1. The Warrantee period, we can guarantee, is one(1) year from your purchasing date</b></p> <p><b>2. Warrantee Exception Clause</b></p> <ul style="list-style-type: none"> <li>- Warrantee period is expired.</li> <li>- Any kinds of Mal-function or defection caused by Modification or Repair without Sewhacnm's permission.</li> <li>- Any kinds of Mal-function, Defection, or External damage, caused by operator</li> <li>- Any kinds of Mal-function, Defection, caused by using spare part from Non-Authorized Distributor or Agent.</li> <li>- Any kinds of Mal-function, Defection, caused by not following Warnings or Cautions mentioned on this manual.</li> <li>- Any kinds of Mal-function, Defection caused by "Force Majeur", like Fire, Flood.</li> <li>- Without presentation of this "<b>Warrantee Certification</b>".</li> </ul> <p><b>3. Other</b></p> <ul style="list-style-type: none"> <li>- Any kinds of "Warrantee Certification" without authorized Stamp is out of validity</li> </ul>	
<p><b>SEWHACNM Co.,Ltd.</b></p> <p>302, 102dong, Ssangyong 3<sup>rd</sup>, Bucheon Techno Park, Seokcheon-ro397beon-gil, Ojeong-Gu, Bucheon City, GyungGi-Do, KOREA</p> <p><b>Made in KOREA</b></p> <p>Website : <a href="http://www.sewhacnm.co.kr">http://www.sewhacnm.co.kr</a> ,</p> <p>Email : <a href="mailto:sales@sewhacnm.co.kr">sales@sewhacnm.co.kr</a></p>	<p><b>Product</b></p> <p>Digital Weighing Indicator</p>
	<p><b>Model</b></p> <p>SI 300</p>
	<p><b>Serial No.</b></p>
	<p style="text-align: center;">AUTHORIZED STAMP</p> <div style="text-align: center;">  </div>